



1. Bow Plate, SS on centerline
2. Shroud Tang, in deck boss (2)
3. 12" jib track (2)
4. Jib Fairlead car, adjustable (2)
5. Fairlead block Seaway #5-030 (2)
6. Cam Cleat (2)
7. Cam Cleat with Fairlead (6)
8. Double Fairlead Block (2)
9. Hiking Strap Retainer Bar (4)
10. Single Cheek Block (2)
11. Double Cheek Block (2)
12. Bronze eye bolt (2)
13. Traveler Bar SS (1)
14. Traveler Car SS (1)
15. Ratchet Block (1)

16. Barney Post Standard without compass (1) fasten with #10 x 1 1/4" DHSMS (9)
17. Compass - optional
18. Padeye on Centerboard with 2 1/2" wire pennant
19. Padeye with single block
20. Padeye (2) SS
21. Hiking Strap Retainer Bar
22. Mast Step Aluminum
23. Fairlead

Sheets and Control Lines

- A. Center Board hold down shock cord 3/8" x 9'-0"
- B. Center board lift control line 5/16" x 19'-0" Braided Dacron
- C. Hiking Straps 2" wide x 20'-0" long Dacron webbing
- D. Cunningham control Line 5/16" x 19'-0" braided Dacron
- E. Main Sheet 3/8" x 27'-0" braided Dacron
- F. Jib Sheet 3/8" x 35'-0" braided Dacron
- G. Traveller Control Line 1/4" x 15'-0" braided Dacron

- H. Cunningham Attachment Line 1/4" x 6'-0" braided Dacron
- I. Hiking Strap Hold up shock cord 3/8" x 3'-0"
- J. Downhaul 3/16" x 4'-0" braided Dacron
- K. Outhaul 3/16" x 4'-0" braided Dacron
- L. Trapeze Retainer line shock cord 3/16" x 8'-6" (opt)
- M. Outhaul (opt type) 3/16" x 10'-0" Braided Dacron
- N. Boom Vang Line 1/4" x 12'-0"
- O. Trapeze Adjuster 3/16" x 3'-6" braided Dacron