



Cut wires to approx 80mm lengths, see note below
 After basic assembly drill holes in bottom panel
 to match side panel
 Start at the transom and fit wires through holes
 and twist together.
 Initially only hand tight, then tension fully after
 fitting a few wires.
 At first fit every other wire then go back
 and add wires as necessary.
 Ensure the side piece lies on
 top of the bottom panel,
 that it is a snug fit and it
 forms a fair curve
 You will only need to fit a
 couple of wires on the CL seam



Note, you can use cable ties or
 nylon fishing line instead of wire.
 However the wires allow you to
 adjust the tension, tight or loose, easily
 I prefer copper wire as it is ductile,
 steel wire tends to snap
 After wiring up you should push
 the wire tight against the hull
 on the inside, see right
 That way it is a smoother surface
 when glassing
 I usually use scrap household
 solid electric wire.
 You will need about 6m (20ft)

