


1in x 1in gunwale

**Inner stem 1in thick
bevel edges approx 6mm**



1400

250


650

495

Drill approx 3mm holes at 100mm centres approx
and approx 6mm in from bottom edge of hull side panels
Hole diameter depends on wire used.

1in x 1in reinforcing on inside hull panels
Fit before assembly - make handed pair!
Ensure panels are exactly the same size before assembly
Also check that the bottom panel is exactly symmetrical
as it is these curves that gives the shape to the boat

50mm wide ply butt strap
on inside face



1200

Cut along the CL joint in the bottom panel

50mm wide ply butt strap
on inside face finish 6mm short of edges

Mark a clear CL on both sides of bottom panel
and bulkheads to assist setting up

**Basic Rowboat, for sailing and nesting
versions see other sheets**

DUO
2 Panel Framing
Copyright WOODS DESIGNS 2014
www.sailingcatamarans.com